



# UHF SERIES ADAPTERS




*double UHF male (50Ω,75Ω)*  
**U-311**




*UHF male-UHF female (50Ω,75Ω)*  
**U-312**




*UHF male-UHF female (50Ω,75Ω)*  
**U-P312**




*double UHF female (50Ω,75Ω)*  
**U-322**




*double UHF female bulkhead receptacle (50Ω,75Ω)*  
**U-332**




*double UHF male right angle (50Ω,75Ω)*  
**U-411**




*UHF male-UHF female right angle (50Ω,75Ω)*  
**U-412**




*double UHF female single UHF male T type (50Ω,75Ω)*  
**U-512**




*three UHF female T type (50Ω,75Ω)*  
**U-522**



*UHF male-BNC female (50Ω,75Ω)*  
**UB-312**



*UHF male-F female (50Ω,75Ω)*  
**UF-312**



*UHF female-F female (50Ω,75Ω)*  
**UF-322**

